

18-Gallon MedSafe™ Inner Liner



Thank you for using MedSafe for the safe disposal of your unwanted pharmaceuticals and over-the-counter drugs. Proper disposal of these materials reduces the potential for harm to our environment, and protects public health.

Do's

- For unused drugs including legally held controlled drugs and narcotics. (Schedule II, III, IV, and V)
- Drugs should be left in original containers when possible with personal information removed if desired.

Don'ts

1. **DO NOT** place needles, syringes, lancets, injection pens, chemotherapy waste or other medical waste in this receptacle.
2. **DO NOT** place batteries, aerosol spray cans, trash or other hazardous materials in this receptacle.
3. **DO NOT** dispose of illicit drugs (Schedule I controlled substances) such as marijuana, cocaine, heroin, methamphetamine.

Notice 1 - Packages may only be shipped from within the 50 US states, District of Columbia, and Puerto Rico.

Notice 2 - Only MedSafe liners provided by Sharps Compliance Inc. will be accepted for destruction.

Instructions For Use

This inner liner Step Log, provided in the final packaging pouch, may be used by those authorized to collect controlled substances from ultimate users to record required information per 21 CFR Part 1304.22(f)(2).

1. When Liner is full remove from inside of receptacle.
2. Remove contents of Final Packaging Pouch.
3. Seal both 4 mil bags with included tie wraps.
4. Close box securely following the number sequence.
5. After the first 3 flaps are closed remove tape backing from 3 strips of double sided tape.
6. Press final flap, with double sided tape, down firmly so that tape adheres to inner flaps.
7. Apply 2 strips of Tamper Tape to both sides of the box as shown.
8. Record your serial number from the top of the liner for future reference.
9. If controlled premises is a long-term care facility, do not store over 3 days in secured room.
10. Hand the sealed Liner to your UPS driver or call Sharps Compliance to schedule a pick-up.

The prepaid UPS shipping label is attached to the top of the box.



Remove contents of Final Packaging Pouch



Apply 2 strips of Tamper Tape to both sides of the box

Contact 800.772.5657 with questions regarding packaging or shipment of your materials

100916 REV B